

## Floor Mat Grip Tape

### Installation Instructions



*Read instructions all the way through before installing Grip Tape*

Each roll of Floor Mat Grip Tape comes with a clear protective film covering the roll to prevent any debris from sticking to the tape during delivery.

First, remove this clear film around the roll.

Second, begin unrolling the tape to the desired length needed. Once the necessary amount of tape is pulled away from the roll, cut the tape with a pair of scissors or utility knife.

Once removed from the roll, adhere the exposed (sticky) side of the tape to the underside of the mat. (For longer pieces, you may want to pull out the length of tape needed and adhere it to the back of the mat as it's pulled out and before cutting the tape to make it easier to apply.)

There should be one piece of tape for each side of the mat. (The tape should always be placed a few inches from the edge of the underside of the mat).

After all of the strips are cut from the roll of tape and adhered to the bottom of the mat, peel off the yellow protective backing from each piece of tape so that the second sticky side is exposed.

Once all of the yellow protective film is removed from each piece of tape, flip the mat over and press it firmly onto the floor (it's best to walk all over the mat to ensure that both sticky sides are secured to the both the mat above and floor below).

The tape should last for many years if the mat is never moved/taken up for cleaning. If the mat is picked up with any frequency, the tape may need to be replaced more often.

Feel free to email at [help@americanfloormats.com](mailto:help@americanfloormats.com) or call us at 800-762-9010 with any questions.